

KM-4850W



The KM-4850W uses a **mechanical counter** located on the right hand side of the machine just below the power switch.

Your meter reading can be taken directly from this counter.

Note: On some machines there may be two counters. We use the counter closest to the front of the copier.

