

KM-8030




The KM-6030 and KM-8030 use an **electronic counter** to record the copy counts. This can be read off the LCD display or printed out in a report.

Use the following steps to check the electronic copy count or print the report.


STEP 1 Press the **Default Setting / Counter** button on the Operator Panel. The default screen will appear on the display.



STEP 2 Press the **Counter Check** button on the display. The total number of copies will be displayed.



STEP 3 To print the report press the **Print Status Page** button on the LCD display.



STEP 4 Press the **CLOSE** button on the display to return to normal copy mode.