



KYOCERA
we'll save you the Earth
KM-C4035E




The KM-C2525E, KM-C3225E, KM-C3232E and KM-C4035E Copiers use an **electronic counter** to record the copy counts. This can be read off the LCD display or printed out in a report.


Use the following steps to check the electronic copy count or print the report.

Note: you need to report the totals for Monochrome, Mono Colour and Full Colour.


STEP 1 Press the **System Menu / Counter** button on the Operator Panel. The default screen will appear on the display.



STEP 2 Press the **Check the Counter** button on the touch display. The total number of copies will be displayed.



STEP 3 To print the Counter Report press the **PRINT REPORT** key on the display.



STEP 4 Press the **CLOSE** key on the touch screen to return to normal COPY mode.

